


Straight Fabric Stand Assembly Instructions

FABRIC

240g Tension Fabric
280g Blockout Fabric


DISPLAY SIZE

8FT、10FT、20FT




01

Put all tubes and plates in order.




02

Insert the L shaped tubes to the feet separately.



03

Connect all the tubes with the same number together to form a square frame. Make sure the thumb buttons slide into places.



04

The a square frame with two feet is completed.



05

Wear the graphic to the frame. To fully and snugly fit the frame, the fabric may be a little tight, so please pull it slowly.



06

Set the fabric stand upright, and start to showcase your brand.